

# Cannot clear a "Power Supply" alarm with USB DIO module attached

The alarm is being generated by the USB DIO module attached to the system. To remove:

## Windows

1. If logged in as the OS user, close the exacqVision Client by pressing Alt+F4.
2. Log out of the user and into admin by selecting Start > Log Out > select admin > type **admin256** > press Enter. Note: **admin256** is default. If this has been changed, please contact your system administrator to log in.
3. Close the exacqVision Client if it opens with Alt+F4.
4. Open Notepad++ by selecting Start > Notepad++.
5. Select Open > navigate to C:\Windows and open usbdio.ini
6. Add the following line to the bottom of the file **psalarms=0**
7. Save and exit Notepad++.
8. Restart the exacqVision Server service through Windows Services. Select Start > Services > right-click exacqVision Server service and select Restart.
9. Open the exacqVision Client using the icon on the desktop.
10. Verify the "Power Supply" alarm has cleared.

## Linux

1. If logged in as the OS user, close the exacqVision Client by pressing Alt+F4.
2. Log out of the user and into admin by selecting the "Lightswitch" icon > Log Out > select admin > type **admin256** > press Enter. Note: **admin256** is default. If this has been changed, please contact your system administrator to log in.
3. Close the exacqVision Client if it opens with Alt+F4.
4. Open a Terminal by double clicking the Terminal shortcut on the desktop **or** selecting Applications > Accessories > Terminal.
5. Type **sudo gedit /etc/usbdio/usbdio.ini** and press Enter. Enter the admin password when prompted.
6. Add the following line to the bottom of the file **psalarms=0**
7. Save and exit gedit.
8. In the open Terminal type **sudo /etc/init.d/edvrserver restart** to restart the exacqVision Server service.
9. Open the exacqVision Client using the icon on the desktop.
10. Verify the "Power Supply" alarm has cleared.