Cloudvue

Cloudvue Gateway Quickstart

Cloudvue Gateway Quickstart Guide

1. PLUG THE GATEWAY INTO YOUR NETWORK

Connect an Ethernet cable from a router which has access to the Internet to <u>PORT #1</u> on the back of the Gateway. If you are using a PoE switch for your cameras, plug that into PORT #2 on the back of the Gateway and then plug your cameras into the PoE switch.

2. GET THE CLOUDVUE MOBILE APP

Install the Cloudvue mobile app, get it for free from the Apple App Store or the Google Play Store. If have you already have a Cloudvue account, click LOGIN. If you do not, click on CREATE ACCOUNT.

3. REGISTER THE GATEWAY

In the Cloudvue mobile app, click on the + sign in the upper right corner. Click on ADD CLOUD GATEWAY. Enter a NAME for the gateway then click on SCAN BARCODE to <u>scan the MAC</u> address of the gateway or manually type it in. Then click on the ADD button.

4. LOGIN ONLINE

Go to: <u>www.cloudvue.ai</u> from your web browser (Google Chrome preferred) and click on LOGIN then click on CLOUDVUE. Login with the same credentials as the mobile app.

5. ADD CAMERAS

Once logged in, click on SETTINGS and then click on DEVICES, then click on SCAN FOR DEVICES. The system will automatically find any compatiable cameras on your network, click on the ADD button to add them to the Gateway.

5. GET SUPPORT

Contact your authorized Cloudvue dealer for the fastest technical support or call us at (888) 754-4543.

www.cloudvue.ai/support