Configuring Samba (SMB) Shares on exacqVision S-Series Enterprise Could Fail After Repartitioning a Drive

If an exacqVision S-Series Enterprise system is configured for Samba (SMB) shares, and then the number of partitions on the drive is changed, configuring a Samba share on the new partitions could fail.

As a workaround, first configure the new partitions for extended storage to ensure that partitions are properly formatted.

